## 0222

BLUE	0V	)		( 0V ORANGE	
		) j	İ	j (	
		) i	i	l (	0.042A
		; i	i		
		<u>,                                    </u>	l		
		/ I	ŀ	( 245V ORANGE	
		<i>)</i>	ļ	( Z45V ORANGE	
		) [	ļ		
		) [	ļ		
RED	115V	)	ļ		
BLACK	0V	)			
		)		( OV PINK	
		) j	İ	į (	
		) j	İ	j (	1.2V
		) i	i	l (	
		í i	i	( 12V PINK	
		/	l	\	
		<i>)</i> [	ŀ		
DDOIDI	115.	)	ļ		
BROWN	TTPA	)	ļ		

For 230V: Join RED & BLACK. Use BLUE & BROWN

For 115V: Join BLUE & BLACK OV and join RED & BROWN 115V.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY

Just cut short and isolate any spare connections

NOTE: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.