

0231

BLACK	0V	_____)	(_____	420V ORANGE	
)	(0.2A
BLUE	10V-	_____)	(_____	400V PINK	
		JOIN*			
)	(
)	(----- 0V GREY	
)	(
)	(400V PINK	
)	(
)	(420V ORANGE	
WHITE	210V-	_____)	(_____	0V YELLOW	
		JOIN*			3A
)	(-----ct GREEN	
)	(
RED	230V-	_____)	(_____	6.3V YELLOW	
		JOIN*			
)	(
BROWN	250V	_____)	(_____	0V VIOLET	
)	(3A
)	(5V VIOLET	
)	(----- YELLOW/GREEN ELECTROSTATIC SCREEN	
)	(
)	(0V WHITE/VIOLET (1)	3A
)	(
)	(2.5V WHITE/VIOLET (1)	
)	(
)	(0V WHITE/VIOLET (1)	3A
)	(
)	(2.5V WHITE/VIOLET (1)	3A
)	(----- YELLOW/GREEN ELECTROSTATIC SCREEN	

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V BLUE/RED = 220V BLUE/WHITE = 200V

* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves must always be individually joined to make the primary circuit complete. Spare connections not required can be cut short, each colour joined separately and isolated. The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY

Just cut short and isolate any spare connections

NOTE: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.