

0298

BLUE	0V	_____) : (_____	0V ORANGE	
) : (_____	250V ORANGE	0.322A
) : (_____	5V VIOLET (1)	
) : (_____	0V YELLOW (1)	2.5A
RED	120V	_____) : (_____	5V VIOLET (1)	
BLACK	0V	_____) : (_____	5V VIOLET (2)	
) : (_____	0V YELLOW (2)	2.5A
) : (_____	5V VIOLET (2)	
) : (_____	22V GREY	
BROWN	120V	_____) : (_____	0V PINK	0.16A
) : (_____	22V GREY	
) : (_____	10V GREEN	
) : (_____	0V WHITE	0.1A
) : (_____	10V GREEN	
YELLOW/GREEN		_____) : (_____	ELECTROSTATIC SCREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

If the WHITE leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY:

Just cut short and isolate any spare connections

NOTE: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.

0298x

BLUE	0V	_____	:	_____	0V ORANGE	
) (0.322A
			: (
) (_____	250V ORANGE	
			:	_____		
) (_____	5V VIOLET (1)	
			: (2.5A
) (-----	0V YELLOW (1)	
			: (
RED	120V	_____) (_____	5V VIOLET (1)	
			:	_____		
BLACK	0V	_____) (5V VIOLET (2)	
			: (2.5A
) (-----	0V YELLOW (2)	
			: (
) (_____	5V VIOLET (2)	
			:	_____		
) (_____	22V GREY	
			: (0.16A
BROWN	120V	_____) (-----	0V PINK	
			: (
			(_____	22V GREY	
			:	_____		
			(_____	10V GREEN	
			: (0.1A
			(-----	0V WHITE	
			: (
			(_____	10V GREEN	
			:	_____		
			(_____	0V RED/BLACK	
			: (0.1A
			(_____	9V RED/BLACK	
			:			
YELLOW/GREEN		_____	=		ELECTROSTATIC SCREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.

* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

If the WHITE leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY:

Just cut short and isolate any spare connections

NOTE: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.