0902



* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections





* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections



* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

0902x



* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

E0902



* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

U0902t



* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections