0958

BLUE	0V) (ORANGE x2	
) (
) (
) (330V, 0.425mA
) (
) (
) (ORANGE x2	
)		
) (YELLOW x2	
) (
) (ct	GREEN x2	6.3Vct, 4A
BROWN	230V) (
		(YELLOW x2	
BLACK	0V)		
) (YELLOW x2	
) (
) (ct	GREEN x2	6.3Vct, 4A
RED	10V) (
		(YELLOW x2	

* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to Be stripped away and tinned if the leads are shortened. For secondary Windings with solid core leads please follow the same process.

$\underline{\mbox{FOR}}$ FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

 $\underline{\text{NOTE:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.

0958x

BLACK	VO) (ORANGE x2	
) (
) (
) (330V, 0.425mA
) (
) (
) (ORANGE x2	
)		
) (YELLOW x2	
) (
) (ct	GREEN x2	6.3Vct, 4A
RED	110V) (
			YELLOW x2	
BLUE	0V)		
) (YELLOW x2	
) (
) (ct	GREEN x2	6.3Vct, 4A
PINK	10V) (
			YELLOW x2	

* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to Be stripped away and tinned if the leads are shortened. For secondary Windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

 $\underline{\text{NOTE:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.