

If the Grey leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains  $\underline{\text{Trans}}$  formers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.