

9466

BLACK	0V	_____)	(_____	370V ORANGE	
)	(_____		0.1A
BLUE	10V-	_JOIN*_	(_____	350V BLUE/GREY	
)	(_____	330V RED/YELLOW	
)	(_____	300V RED/BLACK	
)	(_____	280V RED/WHITE	
)	(_____	250V BLACK/YELLOW	
)	(_____	0V GREY	
WHITE	210V-	_JOIN*_	(_____	250V BLACK/YELLOW	
)	(_____	280V RED/WHITE	
)	(_____	300V RED/BLACK	
RED	230V-	_JOIN*_	(_____	330V RED/YELLOW	
)	(_____	350V BLUE/GREY	
BROWN	250V	_____)	(_____	370V ORANGE	
)	(_____	2.5V VIOLET	
)	(- - - - -	0V GREEN	4A
)	(_____	2.5V VIOLET	
)	(_____	0V YELLOW	
)	(_____	6.3V YELLOW	5A
)	(_____	12V PINK	
)	(- - - - -	0V PINK/BLACK	0.5A
)	(_____	12V PINK	

To obtain other inputs use as follows: 10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V BLUE/RED = 220V BLUE/WHITE = 200V

* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves must always be individually joined to make the primary circuit complete. Spare connections not required can be cut short, each colour joined separately and isolated. The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary windings with solid core leads please follow the same process.

FOR FLEXIBLE LEADS PRIMARY AND SECONDARY

Just cut short and isolate any spare connections

NOTE: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.