


**9728**



O = denotes start of windings