<u>0409</u>

| | BLUE 0V | | 190V ORANGE | |
|-----|------------|-----------------------|-----------------------------|-------|
| (1) | WHITE 110V |) | ((0V GREY | 0.115 |
| | RED 120V |) | (190V ORANGE | |
| | BLACK OV |) | (OV YELLOW | 1.3A |
| (2) | WHITE 110V |))) | ((3.15V GREEN (| |
| | BROWN 120V |))) | (6.3V YELLOW | |

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber casket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.

This is M019 with world wide primary.