0619t

			11			
	BLUE	0V)		(230V ORANGE	
)	\parallel	(200V PINK	
(1)	WHITE) 110V-join-))		(((_ OV GREY	80mA
	RED	120V)		((<i>(</i>	200V PINK	
	BLACK	0v)		(230V ORANGE	
(2)	WHITE	/				
				((0V YELLOW	1.5A
				(6.3V YELLOW	
	BROWN	1207		(0V VIOLET/green	
				(12.6V GREEN	2.5A
				(15V VIOLET	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.