## **06940**

BLUE	ΟV	)		
		)		
		)		
		)		
WHITE	110V	)		
		)		
		)       (	16V ORANGE	
		)       (		2A
RED	120V	)       (	OV GREY (1)	
		(		
BLACK	0V	)       (	16V ORANGE	
		)		
		)		
		)       (	9V PINK	
WHITE	110V	)       (		2A
		)       (	OV GREY (2)	
		)       (	0	
DDOINI	1 0 0 7 7	)       (	9V PINK )	
BROWN	120V	)		

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.