## 0945

		1.1				
BLUE	0V	)	   (	410V	WHITE/RED x 2	0.28A
		)     )     )	(   (   (	345V	YELLOW/RED x 2	U.20A
		)	(	VO	GREEN x 2	
		, , , ,	(   (   (	345V	YELLOW/RED x 2	
BROWN	230V		(	410V	WHITE/RED x 2	
BLACK	ΟV		   (   (	0V	YELLOW x 2	3A
RED	1 0 77	)     )     )		ct	GREEN x 2	JA
T(LL)	101		(	6.3V	YELLOW x 2	
			   (   (	0V	ORANGE	6A
		111	(	9V	ORANGE	011
			   (	0V	GREY	0 07
			(   (	10V	GREY	0.3A

### \* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary Windings with solid core leads please follow the same process.

## FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

 $\overline{\text{NOTE:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.

### 0945x

BLUE	0.0	)       (	- 410V	WHITE/RED x 2	0.284
		)       (	345V	YELLOW/RED x 2	0.20
		)       (			
		)       (	- 0V	GREEN x 2	
		/       (	_ 345V	YELLOW/RED x 2	
		)			
BROWN	230V	)   (	_ 410V	WHITE/RED x 2	
BLACK	VO	)       (	_ 0v	YELLOW x 2	2.7
		)       ( )       (	-ct	GREEN x 2	3A
RED	10V	)   (	_ 6.3V	YELLOW x 2	
			_ ov	GREY	
		(	1 077	CDEV	0.3A
		(	_ 100	GREY	

#### \* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING

The solid wire inside the sleeving is coated with polyurethane and needs to be stripped away and tinned if the leads are shortened. For secondary Windings with solid core leads please follow the same process.

# FOR FLEXIBLE LEADS PRIMARY AND SECONDARY Just cut short and isolate any spare connections

 ${\hbox{{\tt NOTE:}}\over\hbox{and}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.