

**7605**

BLUE	0V	_____	)		(_____	425V YELLOW	
			)	:	(_____		0.2A
			)		(_____	0V PURPLE	
			)	:	(_____		
			)		(_____	425V GREY	
			)	:	(_____		
			)		(_____	0V PINK (1)	
			)	:	(_____		5A
			)		(__ct__	WHITE (1)	
			)	:	(_____		
			)		(_____	6.3V BLACK (1)	
RED	240V-	_JOIN*_	)	:	(_____	0V PINK (2)	
			)	:	(_____		4A
			)		(__ct__	WHITE (2)	
BROWN	250V	_____	)	:	(_____		
			)		(_____	6.3V BLACK (2)	
			)	:	(_____		
			)		(_____	0V ORANGE	
			)	:	(_____		3A
			)		(_____	5V GREEN	

YELLOW/GREEN = ELECTROSTATIC SCREENS

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

**BLUE/BROWN = 240V    BLUE/RED = 220V    BLUE/WHITE = 200V**

**\* FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

**FOR FLEXIBLE LEADS PRIMARY** - just cut short and isolate any spare Connections

**Note:** A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.