COLOUR CODE

<u>8313</u>								
	BLUE	0V			(350V	ORANGE	
(1))))		((0V	GREY	0.1A
	WHITE	110V)		((350V	ORANGE	
	RED	120V)		 (0V	YELLOW	
	BLACK	0V))		(ct (GREEN	2.5A
(2)	WHITE	110V) 		((YELLOW PINK	
	BROWN	120V) 		((150V	PINK	0.01A

OE4E

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum.