## **8525**

	BLUE	0V	)	(	0V	ORANGE	
			)	(	350V		0.10A
(1)	WHITE	110V	)	( (	700V	ORANGE	
	RED	120V	)	(	VO	VIOLET	2A
	BLACK	0V	)	(	5V	VIOLET	211
(2)	WHITE	110V	)	( ( (ct	0V	YELLOW GREEN	0.50A
	BROWN	120V	)	(	6.3V	YELLOW	
				(	0V	PINK	2.5A
				(	2.5V	PINK	2.5A

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum.