8547

			:			
(1)	BLUE	0V)	(0V ORANGE	0 1 5 7
)	(320V ORANGE	0.15A
	WHITE	110V)	(OV PINK	0.60A
):	((190V PINK	
	RED	120V)	(0V VIOLET	
	BLACK	0V	:	((90V VIOLET	0.10A
(2)	WHITE	110V): 	(0V GREY	8.5A
):	((12.6V	12.6V GREY	
): 	(OV YELLOW	
	BROWN	120V):	((6.3V YELLOW	4A
	YELLOV	N/GREEN	: [= E]	LECTROSTAT	IC SCREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum.