85	73
----	----

BLUE	0V	:	 (ORANGE	
) ·)) :	((ct (GREY x2	1200v @ 0.2A
WHITE	110V)	((ORANGE	
RED	120V):	 (YELLOW	6.3v @ 6A
BLACK	0V)	(YELLOW	0.3V @ 0A
WHITE	110V)) :)) :	 ((VIOLET VIOLET	5v @ 3A
BROWN	120V) 	 Green/yello	w = electro	ostatic screen

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum.