

**8617**

	BLUE	0V	_____	)	:		(	_____	0V ORANGE	
				)	:		(			1.4A
				)	:		(	_____	375V ORANGE	
(1)	WHITE	110V	_____	)	:		(	_____	0V PINK	
				)	:		(			0.10A
				)	:		(	_____	100V PINK	
	RED	120V	_____	)	:		(	_____	0V YELLOW (1)	
				)	:		(			7.75A
				)	:		(	_____ct__	GREEN (1)	
	BLACK	0V	_____	)	:		(			
				)	:		(	_____	6.3V YELLOW (1)	
				)	:		(	_____	0V YELLOW (2)	
(2)	WHITE	110V	_____	)	:		(			7.75A
				)	:		(	_____ct__	GREEN (2)	
				)	:		(	_____	6.3V YELLOW (2)	
	BROWN	120V	_____	)	:		(	_____	0V VIOLET	
				)	:		(			0.5A
	Green/yellow =		_____	)	:		(	_____	20V VIOLET	
	Electrostatic screen			)	:		(			

For 240V: Join RED & BLACK. Use BLUE & BROWN  
(Isolate both WHITES separately)

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.  
(Isolate both WHITES)

For 110V: Join BLUE & BLACK 0V and join both WHITES 110V.  
(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum.