87	63
----	----

	BLUE	0V)		(0V	ORANGE	0 057
)		(250V	GREY	0.25A
(1)	WHITE	110V)		((500V	ORANGE	
	DED	10077)			0V	YELLOW (1)	2 7
	RED BLACK		/		(ct		GREEN (1)	3A
	BERICIC	0 0))		((6.3V	YELLOW (1)	
(2)	WHITE	110V)	ļ	 (0V	YELLOW (2)	3.60A
)))		((ct (GREEN (2)	
	BROWN	120V)		(6.3V	YELLOW (2)	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

<u>Note:</u> A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.