

8829

BLACK	0V	(_____)	(_____)	0V ORANGE	
)	(_____)		0.08A
BLUE	10V-	(_____)	(_____)	250V GREY	
	JOIN*)	(_____)		
)	(_____)	500V ORANGE	
)	(_____)	0V VIOLET	2A
)	(_____)	5V VIOLET	
WHITE	210V-	(_____)	(_____)	0V YELLOW	2.5A
	JOIN*)	(_____)	6.3V YELLOW	
)	(_____)	0V PINK	1.5A
RED	230V-	(_____)	(_____)		
	JOIN*)	(_____)	ct YELLOW	
)	(_____)		
BROWN	250V	(_____)	(_____)	12.6V PINK	
)	(_____)		

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V **BLUE/RED = 220V** **BLUE/WHITE= 200V**

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

FOR FLEXIBLE LEADS PRIMARY - just cut short and isolate any spare connections

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber casket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.