

8886

BLACK	0V	_____)		(_____	112.5V ORANGE (1)	
)		(_____	0V GREY (1)	0.12A
BLUE	10V- _JOIN*_	_____)		(_____	112.5V ORANGE (1)	
)		(_____	112.5V ORANGE (2)	0.12A
)		(_____	0V GREY (2)	
WHITE	210V- _JOIN*_	_____)		(_____	112.5V ORANGE (2)	
)		(_____	0V VIOLET	2.5A
RED	230V- _JOIN*_	_____)		(_____	5V VIOLET	
)		(_____	0V GREEN	1.5A
BROWN	250V	_____)		(_____	6V GREEN	
)		(_____	0V PINK	0.1A
)		(_____	30V PINK	
)		(_____	GREEN/YELLOW IS ELECTROSTATIC SCREEN	

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V

BLUE/RED = 220V

BLUE/WHITE= 200V

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

FOR FLEXIBLE LEADS PRIMARY - just cut short and isolate any spare connections

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber casket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.