8913

				II	1				
	BLUE	0V)			(0V	ORANGE	0.25A
)			(475V	GREY	0.25A
(1)	WHITE	110V)			(950V	ORANGE	
	DED	10077)			(0V	RED/WHITE	0 107
	RED					(120V	RED/WHITE	0.10A
(2)	BLACK	0V)			(0V	VIOLET	3A
	WHITE)			(5V	VIOLET	
)			(0V	PINK	бA
)			(7V	PINK	
)) 		(0V	YELLOW	3A
						(ct		GREEN	
						(6.3V	YELLOW	
					1				

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.