

8944

	BLUE	0V	_____)	:		(_____	0V ORANGE (1)	
)	:		(0.15A
)	:		(-----	360V GREY (1)	
(1)	WHITE	110V	_____)	:		(_____	400V ORANGE/GREY (1)	
)	:		(_____	0V ORANGE (2)	
)	:		(0.15A
	RED	120V	_____)	:		(-----	360V GREY (2)	
)	:		(
	BLACK	0V	_____)	:		(_____	410V ORANGE/GREY (2)	
)	:		(_____	0V VIOLET	
(2)	WHITE	110V	_____)	:		(_____	5V VIOLET	3A
)	:		(_____	0V YELLOW (1)	
)	:		(3A
	BROWN	120V	_____)	:		(_____	6.3V YELLOW (1)	
)	:		(_____	0V YELLOW (2)	
	GREEN/YELLOW		_____)	:		(_____	6.3V YELLOW (2)	
Electrostatic screen)	:		(_____	0V PINK (1)	
)	:		(_____	4V PINK (1)	4A
)	:		(_____	0V PINK (2)	
)	:		(_____	4V PINK (2)	4A

For 240V: Join RED & BLACK. Use BLUE & BROWN
(Isolate both WHITES separately)

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.
(Isolate both WHITES)

For 110V: Join BLUE & BLACK 0V and join both WHITES 110V.
(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires
inside the sleeving are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains
transformers and can be amplified when bolting to your metal work.
Therefore you may find a small rubber gasket or similar material
Is worth fitting to quieten this hum to its' minimum, but please
ensure the frame is grounded to the supply safety earth.