

8952

BLACK	0V	((0V GREY	
)	(0.42A
)	(400V ORANGE/RED	
BLUE	10V- _JOIN*_)	(
)	(425V ORANGE/YELLOW	
)	(
)	(450V ORANGE	
)	(
)	(0V WHITE/GREY	
WHITE	210V- _JOIN*_)	(0.60A
)	(70V WHITE/RED	
)	(
)	(80V WHITE YELLOW	
RED	230V- _JOIN*_)	(
)	(0V GREEN	
BROWN	250V)	(3.5A
)	(10V GREEN	
)	(
)	(0V VIOLET	
)	(2A
)	(5V VIOLET	
)	(
)	(0V YELLOW	
)	(1.2A
)	(6.3V YELLOW	
)	(
)	(0V PINK	
)	(1.41A
)	(7.9V PINK	

To obtain other inputs use as follows:
10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V

BLUE/RED = 220V

BLUE/WHITE= 200V

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

FOR FLEXIBLE LEADS PRIMARY - just cut short and isolate any spare connections.

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.