8989

	DT 11D 011				077	00.11100		
	BLUE 0V)		(<i>(</i>	UV	ORANGE	,	0.12A
(1))))		((440V	GREY	`	0.12A
	WHITE 110V)		((880V	ORANGE		3A
	RED 120V))		 ((0V	VIOLET		
	BLACK 0V			(5V	VIOLET	•	JA
(2)	WHITE 110V) 		 				
	BROWN 120V)		 				

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.