89	90
----	----

	BLUE	0V			0V	YELLOW	3A
			)     )     )	(ct  (		GREEN	JА
(1)	WHITE	110V	)   	(	6.3V	YELLOW	
	RED	120V	)	(	0V	VIOLET	4.7
	BLACK	0V	)	(ct  (t		PINK	4A
(2)	WHITE	110V	)	(     	5V	VIOLET	
	BROWN	120V	)     )	   			

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.