9026

				1.1				
(1)	BLUE	0V)		(PINK	370V 0) 1 E 7)
)		(PINK	3700 0	.IJA
	WHITE 1	10V)		(ORANGE		200V-0V-200V	
)		(0v-	GREY		
	RED 1	20V)		(ORANGE	0.05	05A
(2)	BLACK	0V 110V			(YELLOW		6.3V ct
)	 	((ct	GREEN	6.	
	WHITE 1)		(YELLOW		1.5A
))	 	(VIOLET		
	BROWN 1:	20V)		(ct (VIOLET/	green	5V ct 2A
			į	Ϊİ	(VIOLET		

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

<u>Note:</u> A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.