

9033t

BLACK	0V	_____)	(_____	0V ORANGE	
)	(_____		0.55A
BLUE	10V-	_____)	(_____	380V ORANGE	
	JOIN*)	(_____	0V PINK	
)	(_____	100V PINK	0.03A
)	(_____	15V GREY	
)	(_____	0V VIOLET	0.2A
WHITE	210V-	_____)	(_____	15V GREY	
	JOIN*)	(_____	0V YELLOW (1)	
RED	230V-	_____)	(_____	GREEN (1)	4A
	JOIN*)	(---ct--	6.3V YELLOW (1)	
BROWN	250V	_____)	(_____	0V YELLOW (2)	
)	(_____	GREEN (2)	4A
)	(---ct--	6.3V GREEN (2)	
)	(_____		

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V

BLUE/RED = 220V

BLUE/WHITE= 200V

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

FOR FLEXIBLE LEADS PRIMARY - just cut short and isolate any spare connections

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.