

9238

BLUE	0V	_____)	(_____	500V ORANGE	
)	(_____	0V GREY	
)	(_____	500V ORANGE	250mA
(1)WHITE	110V	_____)	(_____	0V PINK	
)	(_____	ct_ YELLOW	
RED	120V	_____)	(_____	12.6V PINK	5A
BLACK	0V	_____)	(_____	0V WHITE/red	
)	(_____	60V WHITE/red	20mA
(2)WHITE	110V	_____)	(_____	0V VIOLET	
)	(_____	5V VIOLET	3A
BROWN	120V	_____)	(_____		

For 240V: Join RED & BLACK. Use BLUE & BROWN
(Isolate both WHITES separately)

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.
(Isolate both WHITES)

For 110V: Join BLUE & BLACK 0V and join both WHITES 110V.
(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.