9250

	BLUE	0V)	İΪ	(425V	ORANGE	
)	İΪ	(0.18A
)	İΪ	(0V	WHITE	
)	İİ	(
(1)	WHITE	110V)		(
)		(425V	ORANGE	
)				
)				
	RED	120V)		(0V	VIOLET	
				Ħ	(3A
	BLACK	0V)	ļΪ	(5V	VIOLET	
)	ļ ļ			
)	ļ ļ			
(2)	WHITE	110V)		(0V	0V YELLOW	4A
				!!	(
)		(ct	GREEN	
)		(
		100)		(6.3V	YELLOW	
	BROWN	T20V)				

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

<u>Note:</u> A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.