## <u>9261</u>

		:			
	BLUE 0V	)	160V	ORANGE	0.5A
		) ·     )       ) :	( 0V	GREY	U.5A
(1)	WHITE 110V		(  (160V 	ORANGE	
	RED 120V	):	ov	PINK	4A
	BLACK 0V	;       )         ) :	(12.6V	PINK	4A
(2)	WHITE 110V	)       ) :     )	(	VIOLET	0.08A
		):   )    ):	( 0v   (	YELLOW	
	BROWN 120V	):	( 25V 	VIOLET	
	YELLOW/GREE	: EN  = 1	ELECTROSTATIC S	SCREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V.

(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.