

9267

	BLUE	0V	_____)		(_____	0V ORANGE	
)		(0.36A
)		(_____	330V ORANGE	
)		(
(1)	WHITE	110V	_____)		(_____	0V GREY (1)	
)		(4.5A
)		(_____	3.15V GREEN (1)	
)		(
	RED	120V	_____)		(_____	6.3V YELLOW (1)	
)		(
	BLACK	0V	_____)		(_____	9V VIOLET (1)	
)		(
)		(_____	0V GREY (2)	
)		(4.5A
(2)	WHITE	110V	_____)		(_____	3.15V GREEN (2)	
)		(
)		(_____	6.3V YELLOW (2)	
)		(
	BROWN	120V	_____)		(_____	9V VIOLET (2)	
)		(
	YELLOW/GREEN		_____)		(
)		(

For 240V: Join RED & BLACK. Use BLUE & BROWN
(Isolate both WHITES separately)

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.
(Isolate both WHITES)

For 110V: Join BLUE & BLACK 0V and join both WHITES 110V.
(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires
inside the sleeving are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains
transformers and can be amplified when bolting to your metal work.
Therefore you may find a small rubber gasket or similar material
is worth fitting to quieten this hum to its' minimum, but please
ensure the frame is grounded to the supply safety earth.