9271

				:			
	BLUE	0V)		0V	PINK	0.20A
)		(230V	PINK	0.20A
(1)	WHITE	110V)	:	 (0V	GREY (1)	2.5A
				Щ	((3.15V	GREEN (1)	
	RED	120V)	:	((6.3V	YELLOW (1)	2.5A
	BLACK	VO)		(9V	VIOLET (1)	2.5A
(2)	WHITE	110V)		 (0V	GREY (2)	2.5A
					(3.15V	GREEN (2)	
)	:	((6.3V	YELLOW (2)	
	BROWN	120V	•	: : 	((9V 	VIOLET (2)	
	YELLOW	N/GREEN	N	: = I	ELECTROSTATIC S	CREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.