<u>9285</u>

		0	;	,				
	BLUE	0V)	(300V ORANGE (0.2A
)	(0V	GREY		0.ZA
(1)	WHITE	110V)		300V	ORANGE		
	RED BLACK WHITE):) :):):)	(0V	YELLOW		
				((ct GREEN			4A	
				(5.3V	YELLOW		
					0V	VIOLET (1)		2A
				(5V	VIOLET (1)		
	BROWN	120V)		0V	VIOLET (2)		2A
				(5V	VIOLET (2)		
			: 		0V	PINK		1A
					9V	PINK		
2	x YELLO	W/GREE	N =	ELECTROSTA:	ric s	SCREENS		

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.