9288

	BLUE	0V		:     	(	30V	PINK	6A
			)	)	(	0V	YELLOW	0A
(1)	WHITE	110V		) 	(   (	30V	PINK	
	RED	120V		) <b>:</b>     )		40V	GREEN	0.2A
	BLACK	0V		·     )       ) :	(	0V	GREY	
(2)	WHITE	110V		) 	(   (	40V	GREEN	
			)	) :     )       ) :	(	0V	VIOLET	3A
	BROWN	120V		) <b>:</b>     	(	12V	VIOLET	
	YELLOW	/GREEN	J	: _ =	· ELECTROSTA	ATIC SO	CREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V.

(Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V.

(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.