

9412

BLACK	0V	(_____)	(_____)	195V ORANGE	0.45A
		(_____)	(_____)	0V GREY	
BLUE	10V- _JOIN*_	(_____)	(_____)	195V ORANGE	
		(_____)	(_____)		9A
		(_____)	(_____)	0V YELLOW	
WHITE	210V- _JOIN*_	(_____)	(-----ct)	GREEN	
		(_____)	(_____)	6.3V YELLOW	0.1
RED	230V- _JOIN*_	(_____)	(_____)	0V VIOLET	
BROWN	250V	(_____)	(_____)	27V VIOLET	

To obtain other inputs use as follows:

10V tap in place of 0V terminal thus:

BLUE/BROWN = 240V BLUE/RED = 220V BLUE/WHITE = 200V

*** FOR PRIMARY WINDING WITH SOLID CORE WIRE AND SLEEVING**

You will note that the Primary is built up in sections and the two wires in the Blue, White and Red sleeves **must always be individually joined** to make the primary circuit complete. **Spare connections not required** can be cut short, **each colour joined separately and isolated**. The solid wire inside the sleeving is coated with polyurethane and needs to be **stripped away and tinned** if the leads are shortened.

FOR FLEXIBLE LEADS PRIMARY - just cut short and isolate any spare connections

Note: A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.