9418

	BLUE	0V		(0V PINK	2 7
):	(9V PINK	3A
(1)	WHITE 13	10V) :)	(OV VIOLET (•
):	(8V VIOLET (1A 1)
	RED 12	20V) :)		0V VIOLET (
	BLACK	0V	; 	(8V VIOLET (•
) •		scree	11
	WHITE 11	1.077):	(OV VIOLET (3) 1A
	WHITE I		/ 	(8V VIOLET (
	BROWN 12	20V): 	. : 		
2 x	YELLOW/C	GREEN	: =	: ELECTROST	ATIC SCREEN	

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V.

(Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V.

(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$ A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.