## **MW18**

BI	LUE	0V	)	   (   (	180V	ORANGE		0.5A
			)	(   (	0V	GREY		
(1) WH	HITE	110V	)	(   (	180V	ORANGE		
RE	ED	120V	)	   (   (	0V	YELLOW	(1)	6V
BI	LACK	0V	)	(				
			)	( 		YELLOW		
(2) WH	HITE	110V	)	(   (		YELLOW		1A
	BROWN	120V	)	   (	0V	PINK		0.02A
BF			)	(   (	100V	PINK		

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.