## **MW21**

			Ш			
BLUE	0V	)		07	/ ORANGE	0.55A
		)		1088	/ ORANGE	0.55A
WHITE	110V	)				
		)		07	/ YELLOW (1)	4.5
RED	120V	)		(  (ct	GREEN (1)	4A
BLACK	0V	)	     	(   ( 6.3 <sup>r</sup> 	/ YELLOW (2)	
wiitma	11077	)		07	/ YELLOW (2)	4.5
WHITE	110V	)		(   (ct	GREEN (2)	4A
BROWN	12017	)		(  (6.3	/ YELLOW (2)	
NIWOAD	12UV	/	 	 		

For 240V: Join RED & BLACK. Use BLUE & BROWN (Isolate both WHITES separately)

For 120V: Join BLUE & BLACK OV and join RED & BROWN 120V. (Isolate both WHITES)

For 110V: Join BLUE & BLACK OV and join both WHITES 110V. (Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires inside the sleeving are joined together in BOTH cases.

 $\underline{\text{Note:}}$  A certain amount of mechanical hum is prevalent in mains transformers and can be amplified when bolting to your metal work. Therefore you may find a small rubber gasket or similar material is worth fitting to quieten this hum to its' minimum, but please ensure the frame is grounded to the supply safety earth.