

MW70s

BLUE	0V	_____)	(_____	0V ORANGE	
)	(_____	500V GREY	
)	(_____		0.25A
)	(_____	1000V ORANGE	
WHITE	110V	_____)	(_____		
)	(_____	0V YELLOW (1)	
)	(_____ct_____	GREEN (1)	
)	(_____		5A
RED	120V	_____)	(_____	6.3V YELLOW (1)	
)	(_____		
BLACK	0V	_____)	(_____	0V YELLOW (2)	
)	(_____ct_____	GREEN (2)	
)	(_____		2A
WHITE	110V	_____)	(_____	6.3V YELLOW (2)	
)	(_____		
)	(_____	0V VIOLET	
)	(_____		3A
BROWN	120V	_____)	(_____	5V VIOLET	

For 240V: Join RED & BLACK. Use BLUE & BROWN
(Isolate both WHITES separately)

For 120V: Join BLUE & BLACK 0V and join RED & BROWN 120V.
(Isolate both WHITES)

For 110V: Join BLUE & BLACK 0V and join both WHITES 110V.
(Isolate RED & Isolate BROWN)

If the White leads are cut short please ensure the TWO wires
Are joined together in BOTH cases.

Note: A certain amount of mechanical hum is prevalent in mains
transformers and can be amplified when bolting to your metal
work. Therefore you may find a small rubber gasket or similar
material is worth fitting to quieten this hum to its' minimum,
but please ensure the frame is grounded to the supply safety
earth.

This is M070s with world wide primary.